



SASHSTOP INSTALLATION GUIDE

- 1** To protect the customer's door; apply masking tape to both sides of the frame where the jig is then going to be clamped on.
- 2** In order to work out where to locate the *SASHSTOP* on the frame, look where the centre-line of the hinges are fitted and mark the same position on the sub-frame.
- 3** Clamp the jig on to the sub-frame and line up the locating notches on top and bottom of jig, with the centre-line mark.
- 4** Drill pilot holes through the jig using a 6mm drill bit.
- 5** Step/cone drill out the pilot holes, working on 12mm for the top and bottom, and 20mm for the centre.
- 6** Check the *SASHSTOP* faceplate fits flush.
- 7** Fit flat bar into the *SASHSTOP* sash jammer. With the arm in an upright position, fit the flat bar in horizontal position for a right/clockwise motion or a vertical position for a left/counter-clockwise motion.
- 8** Fit *SASHSTOP* into the sub-frame, and use M5 screws to secure.

TOP TIP: Clean out the centre of the hole with a 20mm hole cutter to ensure free movement and operation

For more information please visit: sashstop.co.uk